



matting / athletics / flooring

## GYM PRO CLEANING & MAINTENANCE

The following cleaning and maintenance instructions are recommended to ensure the product maintains its desired appearance and optimal performance level, as well as ensuring a long product life span.

### DAILY CLEANING

- Vacuum daily when the product is in use with a heavy duty "commercial style" vacuum cleaner.

### SPOT REMOVAL

- If a spill occurs, blot excess liquid with a clean, absorbent cloth or paper towel. Spray the affected area with an all-purpose set remover\* and gently blot area until the spot is removed. Grease and oil based stains may require a degreasing chemical.

### GUM REMOVAL

- Using a putty knife, remove excess chewing gum from the surface of the material. If residue remains, a commercial grade solvent based gum remover may be required. For best results, score the surface of the remaining gum. This allows the gum remover to penetrate more effectively. Please refer to the gum remover's directions for detailed instructions.

### PERIODIC MAINTENANCE

- The Gym Floor Cover is subjected to varying environments and traffic levels. Your specific traffic and environmental variants will dictate actual periodic maintenance requirements. When deep cleaning is required, ride-on and walk-behind carpet extractors are recommended. Please refer to your local equipment sales specialist for specific recommendations on types and brands of extractors available.