



DESCALE PROCEDURE

MD44 High-Temp Rack Conveyor

- 1** Turn the power off, and fully drain the machine.
- 2** Disconnect dish detergent while the machine is draining so that no detergent enters the machine during the descaling process.
- 3** Once drained turn the machine on and add approximately 1 litre of Vestec 691 descaler manually while the machine is filling.
- 4** Once the machine is done filling, begin to run empty dishracks through the machine for approximately 10 minutes.
- 5** Turn the power off, then drain the machine. While the machine is draining reconnect the dish detergent and wipe down any residue inside the machine with a clean cloth or sponge.
- 6** Once drained turn the machine on and refill. The machine is now ready to use.
- 7** Descale the machine as required. 1-2 times per month depending on water hardness in your area.



VESTEC 691 DESCALER

Items Required:



Rubber Gloves



Safety Goggles



Vestec 691



Bucket



Clean Cloth (or Sponge)

 Toronto | Niagara Falls | Cambridge

 www.flexoproducts.com

 1-800-263-2540

FLEXO
since 1918
cleaning products